



INTERLUDE™ POWERED SUBWOOFERS

Owner's Guide

- IL100s
- IL120s




CAUTION

RISK OF ELECTRIC SHOCK DO NOT OPEN

WARNING: SHOCK HAZARD, DO NOT OPEN.
AVIS: RISQUE DE CHOC ELECTRIQUE – NE PAS OUVRIR.
CUIDADO: PELIGRO DE CHOQUE ELÉCTRICO – NO ABRIR.

**CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK
DO NOT REMOVE COVER (OR BACK)
NO USER SERVICEABLE PARTS INSIDE
REFER SERVICING TO QUALIFIED PERSONNEL**


THIS INFINITY PRODUCT IS DESIGNED FOR 120-VOLT USE ONLY! FOR DETAILED SAFETY PRECAUTIONS, PLEASE SEE FOLLOWING PAGE IN THIS OWNER'S MANUAL FOR "IMPORTANT SAFETY INSTRUCTIONS."



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.



L'éclair avec le symbole de la flèche, placé dans les limites d'un triangle équilatéral est prévu pour avertir l'utilisateur de la présence de "tension dangereuse" non isolée dans l'enceinte du produit qui pourrait être d'une importance suffisante pour présenter un risque d'électrocution aux personnes.



Le point d'exclamation dans un triangle équilatéral est prévu pour avertir l'utilisateur de la présence d'instructions importantes pour les opérations et l'entretien (service) dans les manuels fournis avec l'appareil.

ATTENTION: POUR EVITER LES CHOCS ELECTRIQUES, INTRODUIRE LA LAME LA PLUS LARGE DE LA FICHE DANS LA BORNE CORRESPONDANTE DE LA PRISE ET POUSSER JUSQU'AU FOND.



Este destello luminoso con un símbolo de punta de flecha dentro de un triángulo equilátero tiene el objetivo de alertar al usuario sobre la presencia de "voltaje peligroso" no aislado dentro de la caja del producto que puede ser de magnitud lo suficientemente grande para constituir un riesgo de choque eléctrico para las personas.




Este punto de exclamación dentro de un triángulo equilátero tiene el objetivo de alertar al usuario sobre la existencia de instrucciones operativas y de mantenimiento (servicio) importantes en la literatura que acompaña el aparato.

CUIDADO: PARA REDUCIR EL RIESGO DE CHOQUE ELÉCTRICO, NO RETIRE LA CUBIERTA (O RESPALDO). DENTRO NO HAY PEIZAS A LAS QUE EL USUARIO PUEDE DAR SERVICIO. REMITA EL SERVICIO AL PERSONAL DE SERVICIO CALIFICADO.

IMPORTANT SAFETY PRECAUTIONS

Read First!



1. **Read Instructions.** All the safety and operating instructions should be read before the product is operated.
2. **Retain Instructions.** The safety and operating instructions should be retained for future reference.
3. **Heed Warnings.** All warnings on the product and in the operating instructions should be adhered to.
4. **Follow Instructions.** All operating and use instructions should be followed.
5. **Cleaning.** Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
6. **Attachments.** Do not use attachments not recommended by the product manufacturer, as they may cause hazards.
7. **Water and Moisture.** To reduce the risk of fire or electric shock, do not use this product outdoors or near water—for example, near a bathtub, wash bowl, kitchen sink or laundry tub; in a wet basement; near a swimming pool; or the like.
8. **Accessories.** Do not place this product on an unstable cart, stand, tripod, bracket or table. The product may fall, causing serious injury to a child or adult, and serious damage to the product. Use only with a cart, stand, tripod, bracket or table recommended by the manufacturer, or sold with the product. Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.
9. **A Product and Cart Combination Should Be Moved with Care.** Quick stops, excessive force and uneven surfaces may cause the product and cart combination to overturn.
10. **Ventilation.** Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from overheating, and these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug or other similar surface. This product should not be placed in a built-in installation, such as a bookcase or rack, unless proper ventilation is provided or the manufacturer's instructions have been adhered to.




11. **Power Sources.** This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company. For products intended to operate from battery power, or other sources, refer to the operating instructions.
12. **Grounding or Polarization.** This product may be equipped with a polarized alternating-current-line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.
13. **Power-Cord Protection.** Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the product.
14. **Nonuse Periods.** The power cord of the product should be unplugged from the outlet when left unused for long periods of time.
15. **Outdoor Antenna Grounding.** If an outside antenna or cable system is connected to the product, be sure the antenna or cable system is grounded so as to provide some protection against voltage surges and built-up static charges. Article 810 of the National Electrical Code, ANSI/NFPA 70, provides information with regard to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna-discharge unit, connection to grounding electrodes, and requirements for the grounding electrode. See Figure A.
16. **Lightning.** For added protection for this product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power-line surges.
17. **Power Lines.** An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits, as contact with them might be fatal.

18. **Overloading.** Do not overload wall outlets, extension cords, or integral convenience receptacles, as this can result in a risk of fire or electric shock.
19. **Object and Liquid Entry.** Never push objects of any kind into this product through openings, as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.
20. **Servicing.** Do not attempt to service this product yourself, as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.
21. **Damage Requiring Service.** Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:
 - a. The power-supply cord or the plug has been damaged; or
 - b. Objects have fallen onto, or liquid has been spilled into, the product; or
 - c. The product has been exposed to rain or water; or
 - d. The product does not operate normally when following the operating instructions. Adjust only those controls that are covered by the operating instructions, as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation; or
 - e. The product has been dropped or damaged in any way; or
 - f. The product exhibits a distinct change in performance; this indicates a need for service.
22. **Replacement Parts.** When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or that have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other hazards.
23. **Safety Check.** Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.
24. **Wall or Ceiling Mounting.** The product should be mounted to a wall or ceiling only as recommended by the manufacturer.
25. **Heat.** The product should be situated away from heat sources such as radiators, heat registers, stoves or other products (including amplifiers) that produce heat.

Figure A.

Example of Antenna Grounding as per National Electrical Code ANSI/NFPA 70



INTERLUDE IL100s, IL120s OWNER'S GUIDE

Table of Contents

ii	Caution
iii	Important Safety Precautions
1	Unpacking the Subwoofer
1	Placement of the Components
2	Controls and Connections
3	Connections
4	Operation
5	Bass Optimization System™
6	Maintenance and Service
7	Specifications

Infinity Interlude Series

The Interlude series of loudspeakers and powered subwoofers continues Infinity's longstanding commitment to accurate sound reproduction. Our proprietary Ceramic Metal Matrix Diaphragm™ (C.M.M.D.™) drivers and Bass Optimization System,™ along with precision dividing networks and rigid, well-braced enclosures, combine to deliver uncompromised performance in any stereo or multichannel home theater.

Unpacking the Subwoofer

If you suspect damage from transit, report it immediately to your dealer. Keep the shipping carton and packing materials for future use.

PLACEMENT

Since the installation of a subwoofer can be somewhat more complicated than installing full-range speakers, it is essential that you read this section very carefully prior to connecting the subwoofer to your system. Should you have questions relating to your installation, it is advisable to call either your dealer or Infinity's Customer Service Department for advice.

The performance of the subwoofer is directly related to its placement in the listening room and how you align the subwoofer with its satellite speakers. Setting the volume of the subwoofer in relationship to the left and right speakers is also of critical importance because it is essential that the subwoofer integrate smoothly with the entire system. Setting the subwoofer's volume level too high will result in an overpowering, boomy bass. Setting the volume level too low will negate the benefits of the subwoofer.

Here are several additional facts on installation that may prove useful. It is generally believed by most audio authorities that low frequencies (below 125Hz) are nondirectional and, therefore, placement of a subwoofer within any listening room is not critical. While in theory it is true that the larger wavelengths of extremely low frequencies are basically nondirectional, the fact is that when installing a subwoofer within the limited confines of a room, reflections, standing waves and absorptions generated within the room will strongly influence the performance of any subwoofer system. As a result, specific location of the subwoofer becomes important, and we strongly recommend that you experiment with placement before choosing a final location.

Placement will depend upon your room and the amount and quality of bass required (for example, whether or not your room permits placement of the subwoofer near either satellite). Be sure to leave a minimum of six inches between the wall and the port on the subwoofer.





Figure 1. This example shows the subwoofer positioned behind the right-channel satellite speaker to re-create the actual location of bass instruments in an orchestra and/or add impact to movie soundtracks.

CONTROLS AND CONNECTIONS

Rear Panel



- ❶ Line-Level Inputs
- ❷ Line-Level Outputs
- ❸ Input Selector
- ❹ Low-Pass Frequency Adjustment
- ❺ Low-Pass Filter Selector
- ❻ Phase Switch
- ❼ AC Cord Input
- ❽ Power Switch

Bass Optimization Controls

- ❾ Bass Optimization System Selector
- ❿ Center-Frequency Adjustment
- ⓫ Bass Optimization System Level
- ⓬ Bandwidth Adjustment


Front Panel




- ⓭ Subwoofer-Level Control

CONNECTIONS

If your receiver/processor does not have subwoofer outputs for the left and right channels or an LFE output:




- Set Input Selector to "Speaker."
- Set Low-Pass Filter to "Off."



1. LOOSEN TERMINALS
2. INSERT BARE END; TIGHTEN TERMINALS


If your receiver/processor has subwoofer outputs for the left and right channels:



- Set Input Selector to "Line."
- Set Low-Pass Filter to "On."

NOTE: Some receivers have a single subwoofer output (do not confuse this with a single LFE output as described below). In that case, it is recommended that you use a Y connector (not included) to maximize performance.

If you have a Dolby* Digital or DTS® receiver/processor with a low-frequency-effect (LFE) output:



- Set Input Selector to "Line."
- Set Low-Pass Filter to "Off."

NOTE: In this case, you do not need to use a Y connector. Simply connect the LFE output on your receiver/processor to either the left or right input on the subwoofer.

OPERATION

Power On

Plug your subwoofer's AC cord into a wall outlet. Do not use the outlets on the back of the receiver.

Initially set the subwoofer's Level Control **13** to the "0" position.

Turn on your sub by pressing the power button **8** on the rear panel.

Turn on your entire audio system and start a CD or movie soundtrack at a moderate level.

Adjust Gain

Turn your subwoofer's Level Control **13** up to the "5" position (half way). If no sound emanates from the subwoofer, check the AC-line cord and input cables. Are the connectors on the cables making proper contact? Is the AC plug connected to a "live" receptacle? Has the power button **8** been pressed to the "On" position? (Note: The Level Control on the front panel will turn green when the power is on.) Once you have confirmed that the subwoofer is active, proceed by playing a CD, record or cassette. Use a selection that has ample bass information.

Set the overall volume control of the preamplifier or stereo to a comfortable level. Adjust the subwoofer's Level Control **13** until you obtain a pleasing blend of bass. Bass response should not overpower the room but rather be adjusted so there is a harmonious blend across the entire musical range. Many users have a tendency to set the subwoofer volume too loud, adhering to the belief that a subwoofer is there to produce lots of bass. This is not entirely true. A subwoofer is there to enhance bass, extending the response of the entire system so the bass can be felt as well as heard. However, overall balance must be maintained or the music will not sound natural. An experienced listener will set the volume of the subwoofer so its impact on bass response is always there but never obtrusive.

Crossover Adjustments

Low-Pass Frequency Adjustment Control **4** – The Low-Pass Control determines the highest frequency at which the subwoofer reproduces sounds. If your main speakers can comfortably

reproduce some low-frequency sounds, set this control to a lower frequency setting, between 50Hz – 100Hz. This will concentrate the subwoofer's efforts on the ultradeep bass sounds required by today's films and music. If you are using smaller bookshelf speakers that do not extend to the lower bass frequencies, set the Low-Pass Frequency Adjustment Control to a higher setting, between 120Hz – 150Hz.

Note: This control will have no effect if the Low-Pass Filter Switch **5** is set to "Off." If you have a Dolby Digital or DTS processor/receiver, the Low-Pass Frequency is set by the processor/receiver. Consult your owner's manual to learn how to view or change this setting.

Phase Control

The Phase Switch **6** determines whether the subwoofer speaker's piston-like action moves in and out with the main speakers, 0°, or opposite the main speakers, 180°. Proper phase adjustment depends on several variables such as room size, subwoofer placement and listener position. Adjust the phase switch to maximize bass output at the listening position.

BASS OPTIMIZATION SYSTEM™

Infinity's Bass Optimization System is a simple-to-use, yet sophisticated, low-frequency calibration system. Each Interlude subwoofer contains a parametric equalizer that you can adjust following the directions below. By following these instructions, you can improve the sound of your system.

The Bass Optimization System Goal

It is a fact of audio that what we hear at low frequencies is determined as much or more by the listening room than by the loudspeaker itself. Placement of the loudspeakers and listeners and the acoustical characteristics of the room surfaces are all important determinants of bass quantity and quality. In most practical situations, there is little that can be done about this, except for patient trial-and-error repositioning of the loudspeakers and listeners. Usually, the practical constraints of a living space and the impracticality of massive acoustical treatment mean that equalization is the only practical solution.

Professional sound engineers routinely employ sophisticated measurement systems and equalizers to optimize speakers to the installation. This was never practical for the home audiophile. This is why the Bass Optimization System was created. It enables you to identify the dominant low-frequency response characteristic of your room. Once you know the problem, the Bass Optimization System provides the tools needed to optimize the low-frequency characteristics of the speakers to the room they are in, exactly as the professional sound engineers do it.

Preparations

Before beginning the bass tests, please check the following:

- Make sure all three Bass Optimization System controls on the subwoofer are turned fully clockwise.
- Make sure the loudness contour (if any) on your receiver/processor/preamp is turned off.
- Set the tone controls (Bass and Treble) to their center or flat positions.
- Bypass all surround and effects features of your receiver/processor/preamp or set to Stereo Bypass.
- If you are using a multichannel surround processor or receiver, make sure all bass-management features are properly set. The Audio channels should all be set to "Small" or "High-Pass" and the subwoofer set to "On."
- Set the Bass Optimization System selector **9** to "On."

For best results, it is recommended that all major furnishings are in place and that all doors and windows in the listening area are in their normal positions. That is, if you normally listen to music with all doors closed, then this is how they should be during this procedure.

To solve a problem, it helps to first identify whether you have one and, if so, what it is. First, play a variety of music and films with energetic bass sounds, like bass guitar, kick drum, keyboards, etc. A kick drum should produce a tight "thump," not a flabby "boom." Bass melody or harmony lines should have notes that are about equally loud. If some notes disappear, or stand out because they are consistently too loud, there is a problem. Disappearing notes have to be handled by moving the listening position, or the loudspeakers, to slightly different locations. Often, but sadly not always, this will be enough. Excesses in bass tend to be most annoying, and energetic resonances that cause "boomy" or "lumpy" bass can be truly aggravating over a period of time. Infinity's Bass Optimization System can fix this.

So, the first step is to exercise your music collection, and listen for low-frequency problems that crop up in several different recordings. Something that only happens in one recording is likely to be a problem in the recording – it happens! If you identify something that is consistently wrong, select a record that shows it very clearly, and put your CD/DVD player into a repeat mode (A-B repeat is especially helpful, because you can isolate a short musical passage).

Set the Bass Optimization System Bandwidth adjustment **12** to a middle position (10 clicks from a fully clockwise position) and set Level adjustment **11** for a -6dB (8 clicks from a fully clockwise position). Then, while the music is playing, sit in your favorite chair and have somebody else slowly adjust the Frequency control **10** from fully clockwise to fully counter-clockwise. At a certain frequency, you should hear the problem lessen and the overall bass performance improve. When you are satisfied that you have found the best frequency, have your assistant vary the Level **11** slowly up and down until you have maximized the improvement. If you have really keen ears, you can also have the Bandwidth control **12** adjusted for maximum benefit.

While the Bass Optimization System allows the listener to fine-tune the bass response to sound best in a particular room, some listeners don't have the skill or desire to adjust their system by ear. In order to facilitate quicker and more accurate results, Infinity has developed an optional test and measurement kit that allows the user to perform a series of measurements and aids him/her in properly setting the Bass Optimization System controls. With the addition of this kit, the Bass Optimization System becomes truly room-adaptive. The kit consists of the following: a test CD, a sound-level meter that is specifically calibrated for low frequencies, and something we call a "Q-Finder," a device to help find the width of the measured curve and, finally, a measurement template. It works as follows. The listener

MAINTENANCE AND SERVICE

plays the tones from the test CD and records the relative output level of each test tone, using the sound-level meter, on the provided measurement template. After all the tones are complete, the template contains a response curve for the frequencies below 100Hz. The user simply notes the frequency of the largest bass peak, calculates the correct amount of attenuation, and uses the "Q-Finder" to determine the width of the curve. These three values are dialed into the Bass Optimization System controls located on the speaker. The entire process takes less than twenty minutes.

If your dealer does not stock the Bass Optimization System test and measurement kit, you may purchase it directly from Infinity. U.S. residents can visit our Web site at www.infinitysystems.com or call 1-800-553-3332. Canadian residents should contact their dealer or call 1-800-567-3275.

The enclosure may be cleaned using a soft cloth, dampened with water only, to remove fingerprints or to wipe off dust.

The grille may be gently vacuumed. Stains may be removed with an aerosol cleaner, following its instructions. Do not use any solvents on the grille.

All wiring connections should be inspected and cleaned or remade periodically. The frequency of maintenance depends on the metals involved in the connections, atmospheric conditions, and other factors, but once per year is the minimum.

If a problem occurs, make sure that all connections are properly made and clean. If a problem exists in one loudspeaker, reverse the connection wires to the left and right system. If the problem remains in the same speaker, then the fault is with the loudspeaker. If the problem appears in the opposite speaker, the cause is in another component or cable. In the event that your Interlude loudspeaker system ever needs service, contact your local Infinity dealer or Infinity directly at 1-800-553-3332 or www.infinitysystems.com for a service center near you.

SPECIFICATIONS

	IL100s	IL120s
Frequency Response:	32Hz – 150Hz (± 3 dB)	28Hz – 150Hz (± 3 dB)
Maximum Amplifier Output: (20Hz – 150Hz with no more than 0.1% THD)	250 watts	500 watts
Crossover Frequencies:	50Hz – 150Hz, 24dB/octave, continuously variable	50Hz – 150Hz, 24dB/octave, continuously variable
Driver:	10" C.M.M.D.	12" C.M.M.D.
Dimensions (H x W x D):	13-3/4" x 13-1/2" x 17"	17-1/2" x 17-1/4" x 19-3/4"
Weight:	32 lb (14.5kg)	45 lb (20.5kg)
 Optional Accessory:		
Bass Optimization Test & Measurement Kit:	Part Number: 335852-002	

Infinity continually strives to update and improve existing products, as well as create new ones. The specifications and construction details in this and related Infinity publications are therefore subject to change without notice.



HA A Harman International Company © 2000 Infinity Systems, Inc., 250 Crossways Park Drive, Woodbury, NY 11797 USA (800) 553-3332 (USA only) www.infinitysystems.com

*Trademark of Dolby Laboratories. DTS is a registered trademark of Digital Theater Systems, Inc. Infinity is a registered trademark of Infinity Systems, Inc. Printed in USA 3/00 Part No. 335839-001