



| Ref. # | Part Number | Description | Qty |
|--------|-------------------|--------------------------------|-----|
| 1 | DVD 22 | DVD22 (120v) | 1 |
| | DVD22/230 | DVD22 (230v) | |
| | DVD 22CP | DVD22 for CP systems | |
| 2 | 309-00PM065-0000 | Foam End Pads | 1 |
| 3 | | Plastic Bag | 1 |
| 4 | 310-000DVD22-0110 | DVD22 Outer Carton (120v) USA | 1 |
| | 310-000DVD22-0010 | DVD22 Outer Carton (230v) EU | 1 |
| | 310-00DVD22B-0110 | DVD22B Outer Carton (120v) USA | 1 |
| | 310-00DVD22B-0010 | DVD22B Outer Carton (230v) EU | 1 |
| 5 | 312-AB220000-0010 | DVD22 Owner's Manual (120v) | 1 |
| | 312-AB220000-0000 | DVD22 Owner's Manual (230v) | 1 |
| | 312-AB22B000-0010 | DVD22B Owner's Manual (120v) | 1 |
| | 312-AB22B000-0000 | DVD22B Owner's Manual (230v) | 1 |
| 6 | | Foam Padding | 1 |
| 7 | 312-KBDVD220-0010 | Warranty Card | 1 |
| | | Plastic Bag | 1 |
| 8 | 555-ADVD22RC-0010 | DVD22 Remote Control | 1 |
| | 555-AVD22BRC-0010 | DVD22B Remote Control | 1 |
| 9 | | AA 1.5v Batteries | 2 |
| 10 | 162-B0001012-0000 | A/V Signal Cable | 1 |
| 11 | | Not Used | |
| 12 | 162-C0001012-0000 | S-Video Signal Cable | 1 |
| 13 | 162-H0001012-0000 | Remote IR Input/Output Cable | 1 |
| 14 | | Warning Card | 1 |
| 15 | | Safety Instruction | 1 |

| | | |
|--|------|---------|
| | Name | PACKING |
|--|------|---------|