


AVR430-630 PACKAGING



Ref#	Part Number	Description	AVR430 120v	AVR630 120v	AVR430 230v	AVR630 230v
1-1	ZQC1101HAWH-2	Right Foam End	X	X	X	X
1-2	ZQC1102HAWH-9	Left Foam End	X	X	X	X
2	ZKC1004HA00-5	Outer Carton 430-120v	X			
	ZKC1104HA00-A	Outer Carton 630-120v		X		
	ZKD0104HA00-9	Outer Carton 430-230v			X	
	ZKD0204HA00-3	Outer Carton 630-230v				X
3		Plastic Bag	X	X	X	X
4	H01-ATALF039ABK-A	AM Antenna Loop	X	X	X	X
5	H01-WAB01200203-9	FM Antenna 120v	X	X		
	H01-WAD01200303-3	FM Antenna 230v			X	X
6	H01-RYC1202HA00-5	Zone II Remote Control	X	X	X	X
7	BE18A03	Remote Control 430-120v	X			
	BE18A04	Remote Control 630-120v		X		
	H01-RYD0101HA00-8	Remote Control 430-230v			X	
	H01-RYD0201HA00-6	Remote Control 630-230v				X
8		Plastic Bag	X	X	X	X
9		Misc. card	X	X	X	X
10	ZKC1113HA00-9	Warranty Card	X	X	X	X
11		Safety Paper	X	X	X	X
12	ZKC1001HB00-6	Owner's Manual 430-120v	X			
	ZKC1101HA00-0	Owner's Manual 630-120v		X		
	ZKD0101HA00-A	Owner's Manual 430-230v			X	
	ZKD0201HA00-4	Owner's Manual 630-230v				X
13		1.5v AA Batteries	X	X	X	X
14		Label-Barcode 430-120v	X			
		Label-Barcode 630-120v		X		
		Label-Barcode 430-230v			X	
		Label-Barcode 630-230v				X
15	H01-WAUSA2103BK-1	Power Cord – 120v	X	X		
	H01-WAD022000BK-2	Power Cord – 230v			X	X