


AVR 225 FRONT-PANEL CONTROLS



- | | | |
|------------------------------------|-------------------------------------|------------------------------------|
| 1 Main Power Switch | 11 Input Source Selector | 21 Set Button |
| 2 System Power Control | 12 Tuning Mode Selector | 22 Input Indicators |
| 3 Power Indicator | 13 Digital Optical 3 Input | 23 Delay |
| 4 Headphone Jack | 14 Digital Coax 3 Jack | 24 Digital Input Selector |
| 5 Selector Buttons | 15 Video 4 Video Input Jacks | 25 Main Information Display |
| 6 Tone Mode | 16 Video 4 Audio Input Jacks | 26 Channel Select Button |
| 7 Surround Mode Selector | 17 Bass Control | 27 Speaker Select Button |
| 8 Tuning Selector | 18 Balance Control | 28 Test Tone Selector |
| 9 AM/FM Selector | 19 Treble Control | 29 Surround Mode Indicators |
| 10 Preset Stations Selector | 20 Volume Control | 30 Remote Sensor Window |