


DPR 1001 FRONT PANEL CONTROLS



- 1** Power Indicator
- 2** Standby/On Button
- 3** Surround Mode Selector
- 4** Surround Select Button
- 5** AM/FM Selector
- 6** Input Source Selector
- 7** Tuning Mode Selector
- 8** Tuning Selector
- 9** Preset Station Selector

- 10** ▼ Button
- 11** Set Button
- 12** ▲ Button
- 13** Door
- 14** Volume Control
- 15** System Configuration Indicators
- 16** Main Information Display
- 17** Input Indicators
- 18** Surround Mode Indicators

- 19** Main Power Switch
- 20** Headphone Jack
- 21** Digital Optical 3 Input
- 22** Input/Output Status Indicators
- 23** Digital Coax 3 Jack
- 24** Video 4 Input/Output Jacks