

# DVD 25 REMOTE CONTROL FUNCTIONS

- 1** Power On
- 2** Power Off
- 3** Subtitle
- 4** Title
- 5** Angle
- 6** Audio
- 7** Test
- 8** Eject
- 9** Setup
- 10** Navigation Buttons
- 11** Info
- 12** Menu
- 13** Pause
- 14** EzMenu
- 15** Skip (Previous)
- 16** Skip (Next)
- 17** Play
- 18** Search Reverse
- 19** Stop
- 20** Search Forward
- 21** Dimmer
- 22** Slow Forward
- 23** Zoom
- 24** Slow Reverse
- 25** Random
- 26** Step Forward
- 27** Video Off
- 28** Step Reverse
- 29** Numeric Keys
- 30** Program
- 31** Check
- 32** Clear
- 33** Repeat
- 34** Light
- 35** A-B Repeat

