






1. Instruction manual ass'y - Accessories (CQXAVR3600/120)



NO	DESCRIPTION	PARTS NO.	Q, ty
1	POLY BAG		1
2	CARD WARRANTY	CQE1A172X	1
3	ANT, AM LOOP	CSA1A032Z	1
4	BATTERY		2
5	INSTRUCTION MANUAL	visit www.harmanindia.com	1
6	FM 1 POL ANT (UL)	CSA1A019Z	1
7	REMOCON ASS'Y (ZONE2)	CARTZR60HKM	1
8	CORD, POWER (UL)	CJA2A070Z	1
9	SHEET, QUICK SETUP GUIDE		1
10	STAPLE		3
A	REMOCON ASS'Y	CARTAVR3600/120	1
B	MICROPHONE ASS'Y	CJXAVR340MICRO	1
C	BRIDGE 3	CXZBRIDGE3-HK	1

2. Package Drawing



NO	DESCRIPTION	PARTS NO.	Q, ty
1	ACCESSORYS	CQXAVR3600/120	1
2	REMOCON ASS'Y	CARTAVR3600/120	1
3	SNOW, PAD (L)	CPS5A564Z	1
4	SNOW, PAD (R)	CPS5A565Z	1
5	AVR 3600	AVR 3600	1
6	BOX, OUT CARTON	CPG1A891X	1
7	MICROPHONE ASS'Y	CJXAVR340MICRO	1
8	BRIDGE 3 ASS'Y	CXZBRIDGE3-HK	1