
Fold Method for User Manual



he Bluetooth* word mark and logos are registered trademarks wned by Bluetooth SIG, Inc. and any use of such marks by HARMAN nternational Industries, Incorporated is under license. Other

marks and trade names are those of their respective owners.

CAUTION
RISK OF EXPLOSION IF BATTERY IS REPLACED
BY AN INCORRECT TYPE
DISPOSE OF USED BATTERIES ACCORDING
TO THE INSTRUCTIONS

To register for warranty in India scan OR

ARMAN International Industries, Incorporated 600 Balboa Boulevard, Northridge, CA 91329 USA

Incorporated, registered in the United States and/or other countries. Features, specifications and appearance are subject to change without

10) Voice Assistant 語音助手 음성 비서

11 Specifications

Hit power button twice continuously to activate such voice assistant as Siri, Google Assistant, or the one pre-installed in your phone. 連續按兩次電源按鈕以開啟語音助手,例如Siri, Google Assistant或手機中預裝的語音助手。 전원 버튼을 동시에 두 번 누르면 Siri, Google Assistant 또는 휴대폰에 사전 설치된 음성 비서를 활성화할 수 있습니다.

Driver Size: 12mm

Dynamic frequency response range: 20Hz~20kHz

Maximum SPL: 102dB @ 1kHz

Microphone sensitivity@1kHz dB v/pa:-38dBFs±5

Impedance: 320

Bluetooth transmitted power: -6-4dBm

Bluetooth transmitted modulation: GFSK T/4-DQPSK 8DPSK

Bluetooth frequency: 2.402GHz~2.48GHz

Bluetooth prefiles: HFP V1.7, A2DP V1.3, AVRCP V1.6

Bluetooth prefiles: HFP V1.7, A2DP V1.3, AVRCP V1.6

Bluetooth version: 5.0

Polymer Li-ion Battery: 85mAh 3.7V

Charging time: 1.5hrs

Music play time with BT on: 50%volume about 7hrs

Talk time with BT on: 50%volume about 7hrs

Talk time with BT on: 50%volume about 7hrs

To guarantee your personal safety, please ensure that these headphones are not worn or kept in the immediate vicinity (closer than 10 cm) of a pacemaker.

Do not insert jack plug into electric sockets.

Supervise children when using the equipment. The product is not toy.

Power on : x3

Power off On[©]1.0s

BT Pairing
BT Connected
BT Connected
BT Working
BT Working
BT Working
BT Slow
Fast x4

BT配對 BT已連接 BT工作中

電池電量低

헤드폰 모드

蓝燈亮3次

紅藍燈快閃藍燈慢閃藍燈慢閃

紅煙快速亮4次藍燈亮

● 紅燈亮

LED 상태

