

AVR 125 REMOTE CONTROL FUNCTIONS

- 1** Power Off Button
- 2** IR Transmitter Window
- 3** Program Indicator
- 4** Power On Button
- 5** Input Selectors
- 6** AVR Selector
- 7** AM/FM Tuner Select
- 8** Test Button
- 9** Sleep Button
- 10** Surround Mode Selector
- 11** Night Mode
- 12** Channel Select Button
- 13** ▲ Button
- 14** ◀ Button
- 15** Set Button
- 16** Digital Select
- 17** ▼ Button
- 18** Numeric Keys
- 19** Tuner Mode
- 20** Direct Button
- 21** Tuning Up/Down
- 22** Macro Buttons
- 23** Transport Controls
- 24** Skip Up/Down Buttons
- 25** Disc Skip Button
- 26** Preset Up/Down
- 27** Clear Button
- 28** Memory Button
- 29** Delay/Prev. Ch.
- 30** ▶ Button
- 31** Speaker Select
- 32** Spare Button
- 33** Volume Up/Down
- 34** TV/Video Selector
- 35** 6-Channel Direct Input
- 36** Mute

