



1. Instruction manual ass'y - Accessories



NO	DESCRIPTION	PART NO.	Qty
1	POLY BAG		1
2	CARD WARRANTY	CQE1A172X	1
3	ANT, AM LOOP	CSA1A032Z	1
4	BATTERY		3
5	CORD, POWER	CJA2A070Z	1
6	REMOCON ASS'Y	CARTAVR1566-HK	1
7	SHEET, QUICK START GUIDE		1
8	FM 1 POL ANT(UL)	CSA1A019Z	1
9	SHEET, FRONT COVER		1
10	SHEET, IMPORTANT		1
11	STAPLE		3

2. Package Drawing

AVR 1565 or AVR 1566



NO	DESCRIPTION	PART NO.	Qty
1	OWNER'S MANUAL	visit www.harmankardon.com	1
2	FOAM PAD, (L)	CPS5A564	1
3	FOAM PAD, (R)	CPS5A565	1
4	AVR 1565 or AVR 1566		1
5	BOX, OUT CARTON	CPG1A937Z	1