

DCR600II PACKING/ACCESSORIES

Description	Part Number
Cinema Propack™ 600II System Outer carton	WG5359
DCR600II Outer carton	55281240
DCR600II Remote Control	55251910
Cinema Propack™ 600II System Owner's Manual	(N/A) Download PDF copy on-line
Foam End - Left	55192670
Foam End - Right	55192680
AM Antenna Loop	55127490
FM Antenna cable 75Ω	55127450
Five pairs of speaker cables, receiver to sats:	
Blue	sal5009-1
Yellow	sal5009-2
Green	sal5009-3
White	sal063
Red	sal063
15 foot cable set, receiver to subwoofer	sal063-52
5 foot triple, red/wht/yellow RCA cable, DCR600II receiver to TV set	55176530
3 foot single orange RCA cable, DCR600II receiver to DVD600II	55186190
3 foot single yellow RCA cable, DCR600II receiver to DVD600II	55192120
1 single mini-phono jack for remote in/out	J94310004000