



1. Instruction manual ass'y - Accessories



| NO | DESCRIPTION | PARTS NO. | Q.ty |
|----|---------------------------|-----------|------|
| 1 | POLY BAG | | 1 |
| 2 | CARD WARRANTY | CQE1A172X | 1 |
| 3 | AM LOOP ANTENNA ASS'Y | CSA3A012Z | 1 |
| 4 | BATTERY | | 3 |
| 5 | INSTRUCTION MANUAL | CQX1A949Z | 1 |
| 6 | FM 1 POL ANT(UL) | CSA1A019Z | 1 |
| 7 | REMOCON TRANSMITTER ASS'Y | RB30B00 | 1 |
| 8 | SHEET GUIDE | CQE1A227Z | 1 |
| 9 | STAPLE | | 3 |

2. Package Drawing



| NO | DESCRIPTION | PARTS NO. | Q.ty |
|----|----------------|-----------|------|
| 1 | MANUAL ASSY | | 1 |
| 2 | SNOW,PAD(L) | CPS4A564 | 1 |
| 3 | SNOW,PAD(R) | CPS4A565 | 1 |
| 4 | SET | AVR 135 | 1 |
| 5 | BOX,OUT CARTON | CPG1A775Z | 1 |