

AVR 354 WORKSHEETS

Default settings and worksheets

Table A1 – Recommended Source Component Connections

Device Type	AVR 354 Source	Digital Audio Connection	Analog Audio Connection	Video Connections
Cable TV, satellite TV, HDTV or other device that delivers television programs	CBL/SAT	HDMI 2	Analog 1	HDMI 2
DVD Audio/Video, SACD, [™] Blu-ray Disc, [™] HD-DVD player	DVD	HDMI 1	Analog 2	HDMI 1
Media Server, including Harman Kardon [®] DMC 1000	Media Server	Optical 2	Analog 5	S-Video 1
TV	TV	Optical 1	Analog 3	Component 1*
Video game console	Game	Coaxial 1	Analog 4	Composite 1
Any audio or video device, e.g., CD player, camcorder, cassette deck	AUX	Coax Front	Analog Front	Composite Front (not used for audio-only devices)
Recorder	Any	Coaxial 1 or 2 input and Coaxial Output	Analog 4 inputs and outputs	Composite OR S-Video 2 input and output
iPod	The Bridge II	None	The Bridge II	The Bridge II for photo- and video-capable iPod models

* Make this connection only when using the TV source for a non-display device. Do not connect your television's or video display's video output to the AVR at any time.

Table A2 – Source Setting Defaults

	Cable/Sat	DVD	Media Server	Radio	TV	Game	AUX	The Bridge
Surround Modes (Auto Select)	Logic 7 [®] Movie	Logic 7 Movie	Logic 7 Movie	Logic 7 Movie	Logic 7 Movie	Logic 7 Movie	Logic 7 Movie	Logic 7 Movie
Video Input	HDMI 2	HDMI 1	S-Video 1	N/A	Component 1	Composite 1	Composite Front	The Bridge II
Audio Input	HDMI 2	HDMI 1	Optical 2	N/A	Optical 1	Coaxial 1	Coaxial Front	The Bridge II
Resolution to Display	480i	480i	480i	480i	480i	480i	480i	480i
Audio Auto Polling	Analog 1	Analog 2	Analog 5	N/A	Analog 3	Analog 4	Analog Front	The Bridge II
Zone 2 Audio	Analog 1	Analog 2	Analog 5	N/A	Analog 3	Analog 4	Analog Front	The Bridge II

AVR 354 WORKSHEETS

Table A3 – Speaker/Channel Setting Defaults

Audio Input	All Digital and 2-Channel Analog Audio Inputs	6-/8-Channel Analog Audio Inputs*	Your Settings
Left/Right Speakers	ON	ON	
Center Speaker	ON	ON	
Left/Right Surround Speakers	ON	ON	
Left/Right Surround Back Speakers	ON	ON	
Subwoofer	ON	ON	
Left/Right Speakers Crossover	100Hz	Large*	
Center Speaker Crossover	100Hz	Large*	
Left/Right Surround Speakers Crossover	100Hz	Large*	
Left/Right Surround Back Speakers Crossover	100Hz	Large*	
Subwoofer Mode	L/R + LFE	N/A*	
Subwoofer Size	8 inch	N/A*	
Front Left Level	0dB	0dB	
Center Level	0dB	0dB	
Front Right Level	0dB	0dB	
Surround Right Level	0dB	0dB	
Surround Back Right Level	0dB	0dB	
Surround Back Left Level	0dB	0dB	
Surround Left Level	0dB	0dB	
Sub Level	0dB	0dB	

* Note: The 6-/8-Channel Inputs are "direct" inputs whose signals are passed directly to the volume control without any bass management processing. Thus, the speakers are always full-range and cannot be adjusted. The settings are global for the remaining audio inputs.

Table A4 – Delay Setting Defaults

Speaker Position	Distance From Speaker to Listening Position	Your Delay Settings
Front Left	10 feet	
Center	10 feet	
Front Right	10 feet	
Surround Right	10 feet	
Surround Left	10 feet	
Surround Back Right	10 feet	
Surround Back Left	10 feet	
Subwoofer	10 feet	
A/V Sync Delay	0mS	

AVR 354 WORKSHEETS

Table A5 – Source Settings

	Cable/Sat	DVD	Media Server	Radio	TV	Game	AUX	The Bridge
Surround Modes								
Video Input								N/A
Audio Input								N/A
Resolution to Display								
Adjust Lip Sync								
Change Name								N/A
Audio Auto Polling								N/A
Zone 2 Audio								N/A

Table A6 – Audio Effects Settings

	Default	Cable/Sat	DVD	Media Server	Radio	TV	Game	AUX	The Bridge
Tone Control	Off								
Treble	0dB								
Bass	0dB								
LFE Trim	0dB								
Night Mode	Off								

Table A7 – Video Modes Settings

	Default	Cable/Sat	DVD	Media Server	Radio	TV	Game	AUX	The Bridge
Video Mode	Processor Off								
Brightness*	50								
Contrast*	50								
Color*	50								
Sharpness*	50								
Picture Adjust	Auto Fit								
Noise Reduction**	Off								
MPEG Noise Reduction**	Off								
Cross Color Suppressor**	Off								
Film Mode Detect**	Off								

* Note: These settings are only available when the Video Mode is set to Custom.

** Note: These settings are only displayed when Advanced Video Settings is selected.

AVR 354 WORKSHEETS

Table A8 – Surround Modes

	Default	Cable/Sat	DVD	Media Server	Radio	TV	Game	AUX	The Bridge
Auto Select	Logic 7 [®] Movie or native digital format								
Virtual Surround	Dolby [®] Virtual Speaker Reference								
Stereo	7 CH Stereo								
Movie	Logic 7 Movie								
Music	Logic 7 Music								
Game	Logic 7 Game								
Center Width*	0								
Dimension*	0								
Panorama*	Off								

* Note: These settings are only available when Dolby Pro Logic[®] II or IIx Music mode has been selected. Access these settings by selecting the Edit option.

Table A9 – Remote Control Codes

Source Input	Device Type (if changed)	Product Code
Cable/Sat		
DVD		
Media Server		
TV		
Game		
AUX		

Table A10 – System Settings

Feature	Default	Your Settings
Front Panel Dimmer	On 100%	
Volume Units	dB	
Volume Default	Off	
Volume Default Level	-25dB	
Unit of Measure	Feet	
iPod Charging	Off	
Language	English	
HDMI™ Audio to TV	Off	
OSD Transparency	Normal	
Volume/Status Messages	3 seconds	
Menus	5 seconds	
Setup and Slide-In Menus	15 minutes	
Screen Saver	5 minutes	

AVR 354 WORKSHEETS

Table A11 – Zone 2 Settings

Source Input	Default	Your Settings
Status	Off	
Source	Cable/Sat	
Volume	-25dB	
Surround Back Amps	Main Room	